



ITEM	QTY	PART NO.	DESCRIPTION	NOM
1	1	10218	MICROSWITCH	MICROSWITCH
2	1	11898	CLIP	CLIP
3	1	15493	SPRING PIN	GOUPILLE
4	1	16045	DRIVE PINION	PIGNON D'ENTRAINEMENT
5	1	16053	BRACKET, BRINE SIDE	EQUERRE
6	1	16086	BRACKET, MOTOR MOUNTING	Plaque de montage moteur
7	1	16495	LOWER CAM ASSY	CAME ASSEMBLEE
8	1	17797	BRACKET, SWITCH MTG., 3150/3900	EQUERRE DE MONTAGE
9	2	18691	CONNECTOR, WATERTIGHT - 3/8"	PRESSE ETOUPE 3/8"
10	1	18693	CONDUIT INTERDRIVE	GAINÉ
11	1	18963-39	DRIVE GEAR ASSY 3900 ADAPTER	ROUE D'ENTRAINEMENT ASSEMBLEE
12	4	21354	SCREW THM 8 x 16	VIS
13	1	21759	TIE RAP	COLLIER
14	1	40391	MOTOR, DRIVE, 24V, 50/60HZ.	MOTEUR D'ENTRAINEMENT
15	4	BR10231	SCREW, SLOTTED, INDENTED HEX HEAD, 1/4 - 20 X .50	VIS 1/4-20 X 12.7
16	2	BR10302	INSULATOR, LIMIT SWITCH	ISOLATEUR
17	6	BR10872	SCREW, HEX WSH, 8-32 X 17/64	VIS TETE HEXAGONAL 8-32
18	2	BR11080	SCREW, FLAT HEAD, #8-32 X .38	VIS, #8-32 X 3/8
19	4	BR11235	1/4-20 HEX, NUT	ECROU 1/4-20
20	1	BR11709	PIN- CONNECTING ROD	AXE
21	1	BR11774	RETAINING RING	CLIP DE RETENUE
22	2	BR11805	SCREW TC N°4-40 UNC 2A	VIS TC N°4-40 UNC 2A
23	1	BR16050	RING, RETAINING	CLIP DE RETENUE
24	1	BR16051	RETAINING RING	CLIP DE RETENUE
25	2	BR16052	BUSHING	BAGUE
26	1	BR16059	WASHER	RONDELLE
27	2	BR18692	WASHER, SEALING - 3/8"	RONDELLE 3/8"
28	1	BR18726-5	SPACER, INDICATOR	ENTRETOISE
29	1	BR19315	INDICATOR, SERVICE/STANDBY, 3900	INDICATEUR DE SERVICE/STANDBY, 3900
30	1	BU19305	BACKPLATE, 3900, LOWER, ENV	Plaque de montage, 3900, LOWER, ENV
31	1	BU40396	FAISCEAU ELECTRIQUE	WIRE HARNESS
32	1	BU26638	COVER ASSY PRO2 GREY LOWER 3900	COUVERCLE ASSEMBLE GRIS 3900