



Spare Parts Only  
 Replaced by  
 Mechanical Timer  
 see VCTIMER 3230

ITEM	PART NO.	QTY	DESCRIPTION
1	18741-01	1	HOUSING, RIGHT HINGE, CIRCUIT BOARD
2	18749	1	BRACKET, HINGED 6700ET
3	18764	1	SHIELD, CIRCUIT BOARD
4	18895	1	PAD, SWITCH, 3200ET
5	18895-10	1	SWITCH PAD SPACER
6	28010	1	HARNESS POWER
7	28011	1	HOME / STEP JUMPER
8	BR12758	3	SCREW, HEX WASHER, #10 X 3/8"
9	BR14723	1	PIN, HINGE
10	BR15159	2	O-RING, -005
11	BR18735	1	SCREW, HEX WASHER HEAD, #8-18 X 1.50
12	BR18814	1	SPACER, ELECTRONIC HOUSING
13	BU13296	4	SCREW #6-20 * 0.50 long
14	BU27803	1	FRONT LABEL 3200 RM
15	BU28009	1	HARNESS LOW VOLTAGE
16	BU28529	1	CIRCUIT BOARD,3200GFX,24V